



NOTES:

- TRACER WIRE MUST LAY FLAT AND STRAIGHT. NO COILS MAY BE PRESENT
- ALL CONNECTIONS MUST BE SOLDERED AND WATERTIGHT
- TAPE MUST NOT BE DAMAGED OR TORN
- TRACER WIRE RUN MUST NOT EXCEED 300' WITHOUT ADDITIONAL TEST STATION

DRAWN BY: TS
 CHECKED BY:
 SCALE: N.T.S.
 DATE: 07/28/06

COMMUNICATIONS / SERVICE DUCT BANK
 COMPACTION & TRACER WIRE INSTALLATION

RUTGERS
THE STATE UNIVERSITY
 OF NEW JERSEY
 UNIVERSITY FACILITIES
 PISCATAWAY, NEW JERSEY

SK-41