



- NOTES:**
- TRACER WIRE MUST LAY FLAT AND STRAIGHT. NO COILS MAY BE PRESENT
  - ALL CONNECTIONS MUST BE SOLDERED AND WATERTIGHT

- TAPE MUST NOT BE DAMAGED OR TORN
- TRACER WIRE RUN MUST NOT EXCEED 300' WITHOUT ADDITIONAL TEST STATION

- MARKER BALL BURIED NO MORE THAN 4'
- DO NOT CRUSH BALL WHEN INSTALLING OR COMPACTING SOIL
- INSTALL BALLS AT TURNS AND CRITICAL BURIED COMPONENTS

DRAWN BY: TS  
 CHECKED BY:  
 SCALE: N.T.S.  
 DATE: 07/28/06

## MARKER BALL INSTALLATION

**RUTGERS**  
THE STATE UNIVERSITY OF NEW JERSEY  
 UNIVERSITY FACILITIES  
 PISCATAWAY, NEW JERSEY

SK-43