



NOTES:

- TRACER WIRE MUST LAY FLAT AND STRAIGHT. NO COILS MAY BE PRESENT
- ALL CONNECTIONS MUST BE SOLDERED AND WATERTIGHT
- TAPE MUST NOT BE DAMAGED OR TORN
- TRACER WIRE RUN MUST NOT EXCEED 300' WITHOUT ADDITIONAL TEST STATION

DRAWN BY: TS  
CHECKED BY:  
SCALE: N.T.S.  
DATE: 08/06/04

STORM / SANITARY SEWER COMPACTION  
& TRACER WIRE INSTALLATION

**RUTGERS**  
THE STATE UNIVERSITY  
OF NEW JERSEY  
UNIVERSITY FACILITIES  
PISCATAWAY, NEW JERSEY

SK-44